




How do I check and set a charging rate for my public charging station?

User Guide






Log in with your administrator account on the My Mobiflow platform (https://my.mobiflow.be/welcome) and navigate to **Locations** in the **Charging Points** menu.




2 Click on the name of the location and select the **Pricing** tab.








If no charging rate is set, you need to configure one by either creating a new tariff policy, applying an existing tariff policy, or selecting the default CREG tariff policy. Navigate to the Charging Points tab and click Pricing.




To create a new tariff policy, click **Create new policy** at the top and fill in the required pricing components. (*Note: For decimals, use full stops and not commas, e.g. 0.50 instead of 0,50*). Then, click **Create**.






Once the tariff policy is created, you need to link it to the relevant charging point.

Go back to the **Pricing** tab (*Charging Points > Locations*) and click on **Edit pricing** for the corresponding charging point.





6 Select the desired tariff policy.

Tip: Want to adjust the rates of your charging points? Simply update the tariff policy - all associated charging points will be updated automatically, so there's no need to change them one by one.

aat 46/201, 9000 Gent, BE fice
iice
fice
īce
9A⊙
Hourly cost
First 2h: €10.00
After that: €20.00



M mobiflow

Sassevaartstraat 46/box 201 9000 Ghent, België +32 (0)9 296 45 40 info@mobiflow.be www.mobiflow.be