

Introduction

In order to connect your charging station to the Mobiflow platform, it should have a connection with the Mobiflow server. Therefore, insert the URL below in the right place in the charger's software.

For a SIM connection with a Mobiflow SIM card, use the APN: "optimile" and leave the password blank.



Using Mobiflow SIM cards

➔ `wss://proxy.optimile.eu/services/ocppj`

When copied, NO ADDITIONAL SPACES

APN: **optimile**

Password: **leave blank**

(Blanco laten)



Using an Internet Connection (LAN or WiFi)

➔ `wss://proxy.optimile.eu/services/ocppj`

When copied, NO ADDITIONAL SPACES